

ASSEMBLY DRAWING

Parts List:

ITEM	PART NO.	DESCRIPTION	QTY	REMARKS
1	SPA-00001	Cabinet	1	
2	SPA-00006	LED indicator	1	
3	ECW-00005	Key board adapter	1	
4	SPA-00007	Main P.C. board	1	
5	SPA-00008	FDD/HDD controller card	1	
6	SPA-00009	I/O card	1	
7	SPA-00010	Display card	1	
8	CPS-76011	Interface card fixed metal	1	
9	CPS-76018	Interface card plate	2	
10	ECW-00011	25 Pin connector & cable	1	
11	CPP-76019	Side turner grill	1	
12	CPP-76020	Grill cover	1	
13	EPS-00001	Switching power ass'y	1	LCD
	EPS-00005	Switching power ass'y	1	Gas Plasma
14	CPS-76009	S.P.S. fixed metal	1	
15	CPS-76010	FDD/HDD fixed metal bracket	1	
16	ESK-00001	Speaker 1/8W 45ϕ	1	
17	EPD-30001	3½" FDD	1	
18	CPP-76007	Drive grill	1	
19	CPP-76008	FDD grill	1	
20	SPA-00012	Rear panel	1	
21	SPA-00003	Interface card guider	1	
22	SPA-00020	Ext 5¼" FDD adapter	1	
23	CPS-76014	Ext 5¼" fixed metal	1	
24	EHD-30001	HDD 3½" 20M	1	
25	CPN-76006	Insulation plate for main PCB	1	
26	XPC-06323	Screw 6-32 UNC	4	HDD
27	XWI-32085	Insulation washer	6	
28	XUI-35102	Screw 3.5 × 10 TAPI	11	
29	XFS-03083	Screw 3 × 8 P0.5	4	
30	XPS-04103	Screw 4 × 10 P0.7	5	
31	XP4-04203	Screw 4 × 20 TAP	1	
32	ESW-01001	Reset SW RIB-27A	1	
33	XPW-03063	Screw 3 × 6 P0.5	14	
34	XP4-03083	Screw 3 × 8 TAP	2	
35	SPB-04011	LCD Assembly	1	
	SPA-00021	Gas Plasma Assembly	1	